

FORM & FUNCTION

Hiland Tray[™] is a modern 460mm wide tray roofing and walling system, roll formed onsite with a mobile roll forming facility in long single lengths and secret fixed or 'snap locked' to roof purlins and wall girts via a simple clip system. The profile is available with the option of swages within the tray pan, or no swages for a more traditional look.

The Hiland Tray profile has a high rib height of 44mm which enhances its smooth, bold lines and provides greater water carrying capacity and strength for snow loading applications in alpine regions.

Hiland Tray is available in 0.55mm BMT in a selected range of contemporary pre-painted colour options to suit any building design.



MATERIAL SPECIFICATIONS

Material Properties	Finish	0.55mm BMT	
Minimum 'AZ' Coating Mass (g/m²)	Zinc/Al & Colour	150	
Mana (las (listante status)	Zinc/Al	2.74	
Mass (kg/linear metre)	Colour	2.77	
Mana (las (asuras status)	Zinc/Al	5.95	
Mass (kg/square metre)	Colour	6.03	
	Zinc/Al	168	
field (square metre/tonne)	Colour	166	
Tensile Strength (MPa)	Zinc/Al & Colour	340	
Width Coverage (mm)	Zinc/Al & Colour	460	
Sheet Tolerances (mm)	Length & Width	±5 ±2	
Minimum Roof Pitch	Zinc/Al & Colour	3°	

STRATCO HILAND TRAY[™]

DESIGN GUIDE: ROOFING AND WALLING

HILAND TRAYTM DESIGN GUIDE: ROOFING AND WALLING

SPAN TABLES

TABLE 2.0 - MAXIMUM RECOMMENDED SPANS (mm)

Span Type	Roofing BMT 0.55mm	Walling BMT 0.55mm		
End / Double	600	1800		
Internal Span	900	1800		

Roofing : Spans are limited based on foot traffic incidental to maintenance. Walling: Spans are based Region A, Terrain Category 2.0 wind loading, refer to the 'Spans' table below.

TABLE 3.0 - SPANS (mm)



Terrain Category	Local Pressure KI	Roofing				Walling			
		Region A		Region W		Regi	ion A	Region W	
		End / Double	Internal						
1	1	600	900	600	900	1800	1800	1800	1800
	1.5	600	900	600	900	1800	1800	1800	1800
	2	600	900	600	900	1800	1800	1470	1600
	3	600	900	560	620	1320	1450	950	1080
2	1	600	900	600	900	1800	1800	1800	1800
	1.5	600	900	600	900	1800	1800	1800	1800
	2	600	900	600	900	1800	1800	1790	1800
	3	600	900	600	900	1640	1760	1280	1410
3	1	600	900	600	900	1800	1800	1800	1800
	1.5	600	900	600	900	1800	1800	1800	1800
	2	600	900	600	900	1800	1800	1800	1800
	3	600	900	600	900	1800	1800	1800	1800

TABLE 4.0 - WIND CAPACITIES (kPa)

вмт	Span Type	Limit State	SPAN (mm)					
			450	600	900	1200	1500	1800
0.55mm	End / Double	Serviceability	5.23	3.78	3.14	2.57	2.08	1.68
		Strength	6.54	4.73	3.92	3.21	2.60	2.10
	Internal	Serviceability	5.23	3.78	3.14	2.57	2.08	1.68
		Strength	7.15	5.17	4.29	3.51	2.85	2.30

Capacities determined based on a minimum of two screws per clip into timber supports.

NOTE: For roofing applications, purlin tape must be used to create a barrier between Hiland roof sheeting and timber supports for noise reduction.





ENGINEERING

TESTING SYSTEMS

Stratco have developed purpose built testing equipment for the testing of cladding systems sufficient to ensure the structural adequacy of the product it produces.

COMPLIANCE

Wind Capacity Tables are based on testing for compliance with the New Zealand Metal Roof and Wall Cladding Code of Practice. Span tables have been developed by determining relevant wind pressures in accordance with AS/NZS 1170.2. Capacity tables are in limit state format.

SPANS

Span tables are based on maximum overall building height of ten metres and a 500 year design return period for strength limit state wind load assessment. Roofing spans specified are suitable for snow loading up to 2kPa in accordance with the New Zealand Metal Roof and Wall Cladding Code of Practice. Roofing calculations are based on Cpe=-0.9 and Cpi=0.2, walling is based on Cpe=-0.65 and Cpi=0.2. Local pressures are as specified and have been considered for both strength and serviceability limit states. Roof spans take into consideration loads incidental to maintenance noting ends spans allow for foot traffic over supports only.

All pressures have been determined assuming wind loading in any direction without shielding but which is not affected by topography (i.e. Mt=1.0). Allocated spans do not allow for Lee Zones, for areas within these zones, utilise the wind capacity tables to calculate spans based on the relevant allowance for Lee Multipliers.

Additional engineering advice can be obtained from Stratco if any design parameters vary from those indicated above. DESIGN CONSIDERATIONS

Hiland Roofing and Walling has a 460mm cover with a 0.55mm BMT material thickness. The minimum allowable roof pitch is 3°.

FIXING REQUIREMENTS

Hiland sheets should be laid into the prevailing wind and sit neatly on the preceding roof sheet. They should be fixed within the recommended support spacings. Avoid 'stretching' the width of the sheet when installing, as this could allow wind and rain to enter. Edge fixing is mandatory for strength/spanning capability.

This is done with 10 gauge self drilling screws to secure the standing seam to edge clips (i.e. to all clips along edges of sheet layouts).

Due to the seam height, flashing turn downs into the pan of Hiland sheeting should always be notched around the rib to provide maximum weather tightness.

For roof pitches less than 10°, it is recommended that safety mesh is used directly under the Hiland Tray and purlin centres are reduced to 450mm. Use either roofing string or tape to support the underlay.

For roofing applications, purlin tape must be used to create a barrier between Hiland roof sheeting and timber supports for noise reduction.



Two 10x30mm wafer-head timber fixing screws (square drive recommended) per clip. Clips located at every sheet overlap and sheet edges at each timber support. Timber supports to be 100x50mm planer gauged and minimum MGP10 or F5 grade.

WALKING ON HILAND TRAY

When walking on Hiland Roofing, walk over the purlins to avoid damage to the sheeting. Wear flat rubber soled shoes and walk flat footed in the pans only. Walking on end spans is restricted explicitly to over the end span purlins with no access allowed directly on end spans due to potential sheet damage.

MAINTENANCE REQUIREMENTS

The performance of Hiland Roofing and Walling over time depends on its correct application and maintenance. Maintenance should be performed as often as is required to remove any dirt, salt and pollutants.

Where Hiland cladding is used in severely corrosive environments, cleaning should be performed more often. It is important that screws have the same life expectancy as the Hiland cladding you have specified. Packs of Hiland sheeting should always be kept dry and stored above ground level on site. If the sheets have become wet, they should be separated, wiped and placed in the open to dry.

Refer to the Stratco 'Selection, Use and Maintenance' brochure for more detailed information about the correct use and maintenance of this product.



NAPIER ROTORUA MOUNT MAUNGANUI CHRISTCHURCH CROMWELL NELSON BLENHEIM Ph: (06) 843 6159 Ph: (07) 347 4635 Ph: (07) 347 4635 Ph: (03) 338 9063 Ph: (03) 445 0870 Ph: (03) 538 0824 Ph: (03) 577 7720 65 Niven St, Onekawa, Napier 4110 18 Scott St, Whakarewarewa, Rotorua 3010 147 Totara St, Mount Maunganui 3116 55 Hands Rd, Middleton, Christchurch 8024 8 McNulty Rd, Cromwell 9310 41 Venice Pl, Stoke, Nelson 7011 35 Kinross St, Blenheim 7201



All brands and logos/images accompanied by ® or ™ are trade marks of Stratco (Australia) Pty Limited. ® Copyright March 2019